

Toner Mixing Bank Maintenance Satellite Locations

The locations toner mixing bank should ideally run two cycles, twice per week and at a minimum it must run for two cycles, once per week.

Follow instructions in order to agitate or stir toners on the mixing bank.

- 1 Locate the Mixing Timer Switch:
 - 👑 Switch is normally found on the left side when facing the mixing machine.
 - 👑 Mixing Timer Switch images shown below.
- 2 Start the machine.
 - 👑 Press the green button for two seconds and release.
- 3 The mixing bank does not need to be stopped or turned off.
 - 👑 Once activated the machine is programmed to run a preset amount of time, then will turn off by itself.

Mixing Timer Switch

